

HEADREST MOLLE PANELS

(2009-2014 F-150)

INSTALLATION INSTRUCTIONS

CONTENTS

TOOLS REQUIRED

N/A





STEP 1

Lift the vehicle headrest by pressing the (2) release buttons at the base while lifting up on the headrest.



STEP 2

Insert the molle panel onto the headrest posts. Lower the headrest to the desired position. Repeat steps 1-2 to the opposite side of the vehicle.

Installation is now complete.