



# BED TIE DOWN SET

(2015-2020 F-150)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (4) Bed Tie Down Mounts
- (4) Bed Tie Downs
- (16) M6x1.00 x 16mm Allen Bolts
- (1) 4mm Allen Key

### TOOLS REQUIRED

---

- Exterior Detailer
- Microfiber Cloth



---

**STEP 1**

Locate the (4) threaded holes in the vehicle bed side. Clean the area with exterior detailer and a microfiber cloth. Install (1) bed tie down mount to the vehicle bed side using (4) M6x1.00 x 16mm Allen bolts.

Note: Due to some spray-in bed liners/paint, the threaded holes may need to be chased using a thread tap to ensure proper hardware engagement.



---

**STEP 2**

Secure (1) bed tie down to the mount by aligning the cutouts, and secure into place using the key and lock mechanism.

Repeat steps 1-2 to the remaining bed tie down mounts. Installation is now complete.