# **INSTALLATION INSTRUCTIONS**

HD4 HD Front Push Bar 2018-20 FORD F150 T604000




#### T604000

## **Installation Instructions**

### **PARTS LIST:**

Qty	Item Description	Qty	Item Description
1	Push Bar center structure	2	8-1.25mm x 25mm Hex Bolts
1	PS/Right wing Bracket	2	8-1.25mm x 25mm Combo Hex Bolts
1	DS/Left wing Bracket	4	8-1.25mm x 25mm Button Head Allen Bolts
1	License Plate Bracket	2	6-1.00mm x 20mm Combo Button Head Bolts
2	License Plate Bracket Plastic Plugs	1	5mm Allen Wrench
1	PS/right LED Bracket	10	8mm x 24mm x 2mm Flat Washers
1	DS/left LED Bracket	4	8mm x 16mm x 1.6mm Flat Washers
8	12mm Hex Nuts	8	12mm Lock Washers
6	8mm Hex Nuts	8	8mm Lock Washers
2	8-1.25mm x 16mm Hex Bolts	8	12mmx32mmx3mm Flat Washers





Hex Nut



Lock Washer



Flat Washer



Hex Bolt



Button Head Allen Bolt

#### **TOOLS REQUIRED**





13 & 19mm Socket








ions Wrench

1

Follow (Fig 1-5) to remove standard Shackle Mounts and prepare for Push Bar Installation.










ig slot


Follow (Fig 6 - 14) to attach Brackets, then install Push Bar and connect Push Bar Wings. Then reinstall U-covers. Ensure fasteners are hand tight at this point.



















3







Follow (Fig 15 – 18) to attach LED Brackets and LED Bar (not included). Ensure all fasteners are hand tightened at this point.




(Fig 13) Attach LED Bracket to insert on backside of Push Bar

Page 4 of 5 8-5-24 (JY)







Ensure Push Bar is level and properly fit, then tighten all fasteners. Installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.



Page 5 of 5 8-5-24 (JY)