



POWERED TOW MIRRORS WITH PUDDLE LIGHT & AMBER TURN SIGNALS

(2004-2014 F-150)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Mirror
- (1) RH Mirror
- (2) Wiring Harness
- (6) M6x1.00 Flange Nuts

TOOLS REQUIRED

- 6, 8, 10, 11mm Sockets
- Ratchet
- Plastic Pry Tool

SKU # T604416



STEP 1

It is recommended to lower the vehicle window before disassembly. Open the vehicle door.

Using a plastic pry tool, remove the plastic cover behind the door release latch and set the cover aside. Then, use the plastic pry tool to remove the cover along the bottom of the grab handle.

Remove the (2) 8mm bolts from the door panel.



STEP 2

Remove (2) 6mm bolts from the bottom of the door panel.

STEP 3



Lift the door panel upwards to unhook the panel from the door. Disconnect the door release cable from the door release handle, or carefully hang the door panel.

STEP 4



Unplug the mirror connector by pressing the tab inwards. Then, remove (3) 11mm nuts and remove the mirror from the vehicle door.

STEP 5



Fit the new mirror to the vehicle, and secure using the included (3) 10mm nuts.

Note: For ease of installation, connect the included wiring harness to the mirror connector. The extension on the harness will allow easier fitment through the vehicle door during mirror placement.

STEP 6



Depending on vehicle model year, the included wiring harness may or may not be used.

2004-2008 F-150: The wiring harness will be used.

2009-2014 F-150: The wiring harness will not be used.

Test all mirror functions before re-assembling the door panel.



STEP 7

Re-assemble the door following steps 1-3 in reverse order.

Installation is now complete.