



# MOLLE PANEL FOR HEAVY DUTY BED RACK

(UNIVERSAL TRUCK WITH BED RACK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Molle Panel
- (4) T-Slot Threaded Inserts
- (4) M8 x 14mm Allen Bolts
- (4) M8 Lock Washers
- (4) M8 Flat Washers
- (1) 5mm Allen Key

### TOOLS REQUIRED

---

5mm Allen Key/Socket  
Ratchet

SKU # T604419

## STEP 1



Fit (4) M8 T-Slot threaded inserts into the bed rack T-Slot bars.

Use (4) M8 x 14mm Allen bolts, (4) M8 lock washers, and (4) M8 flat washers to secure the molle panel to the bed rack T-Slot bar.

## STEP 2



Ensure all molle panel hardware is fully secure.

Installation is now complete.