




Installation Instructions

PARTS LIST:

Qty	Item Description	Qty	Item Description
1	Bumper Base	8	4mm x 15mm Flat Head Self Tapping Screw
1	DS/Left Mounting Bracket	4	Plastic Plug (Without Sensors) (PP)
1	RS/Right Mounting Bracket	4	Retaining Cap (PP)
4	10mm Plastic Retainers	4	20mm x 10mm Foam Spacers
1	PS/right Fill in Mesh Panel	4	15.5mm x 25mm OD x 2mm Foam Washer
1	DS/left Fill in Mesh Panel	6	19mm Anti-Collision Rubber Pellets
10	200mm Wire Harness Ties	8	10mm x 30mm x 2.5mm Flat Washers
1	PS/Right Support Bracket	8	10mm Lock Nuts
1	DS/Left Support Bracket	4	6-1.00mm x 20mm Combo Bolts
2	10mm x 35mm Bolt Plate	4	6mm Hex flanged Nuts
2	Plastic Plugs for License Plate	2	Parking Sensors Wire Harness Extension
2	10mm x 95mm Double Bolt Plate	6	14mm PVC Plastic retainer



TOOLS REQUIRED













Follow (Fig 1 - 4) to prepare HD4 Bumper for installation by attaching Tow Hook and attaching Plastic Plug and Mesh Panel for vehicles not using parking sensor or LED Light cubes.




Follow (Figures 5-7) to remove factory bumper for the installation of the HD4 Bumper.







(Fig 6B) Remove the factory hex nuts attaching bumper assembly to frame. STD tow package model pictured (no receiver hitch)









Follow (Figure 8 – 13) for models without receiving hitch to attach Mounting Bracket to Bumper, then attach Bumper and Bracket to vehicle. Ensure hardware is hand tightened.







(Fig 10) Attach Mounting Bracket and attached Bumper to Receiver Hitch reusing factory Triple Bolt Plate




- (1) 10mm x 95mm Double Bolt Plate
- (1) 10mm Flat Washer
- (1) 10mm Nylon Lock Nut









Follow (Figure 14 – 19) for models with receiver hitch, attaching Support Bracket to receiver hitch, then attaching Bumper to receiver hitch. Ensure hardware is hand tightened.




(Fig 14) Attach Support Bracket to Vehicle reusing factory Triple Bolt Plate





T619019/T619020




- (1) 10mm x 95mm Double Bolt Plate
- (1) 10mm Flat Washer (1) 10mm Nylon Lock Nut











Follow (Figure 20 - 27) to attach Trailer Plug, Parking Sensors, License Plate, LED Light Cubes, and License Plate Lights.



















(Fig 27) Connect all wiring for Lights and sensors to wiring harness

6

Ensure Bumper is level, then tighten all hardware and double check all wiring connections. At this point, installation is complete. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

