

2024+/FORD F-150

HONEY BADGER FRONT BUMPER

F1900111040103



TOOLS REQUIRED

(Sockets) 9/16, 7mm, 10mm, 13mm, 15mm, 21mm
 (Box end wrenches) 9/16, 7mm, 10mm, 13mm, 15mm, 21mm
 (Allen wrenches) 5/32
 (Torx) T20, T30
 Fastener remover or flathead screwdriver
 Zip ties
 Ratchet
 Jigsaw (or preferred cutting tool)
 Razor/scissors



TIME REQUIRED

- 2 hours for OEM Removal/Bumper Install
 -1 Additional Hour for Wiring

****Labor Rates are based on a vehicle with no pre-existing damage. Wiring labor is based on a standard wiring procedure with light switches installed in an easily accessible location. Custom light triggering or switch mounting location will result in a greater labor charge.****



SKILL LEVEL

-Medium/Moderate

****This installation requires 2 people for best results****



WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION



-BEFORE YOU INSTALL THIS KIT-

Read and understand all instructions, warnings, cautions, & notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.

Customer Service (480) 671-0820

Addictive desert designs is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components.

We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these

components and the safety of the vehicle.


Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information:

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

ALWAYS WEAR EYE PROTECTION WHEN OPERATING POWER TOOLS

HARDWARE/PARTS

A.



3/8-16 X 1 1/4" HEX HEAD BOLT

QTY: 6

A1.



3/8" FENDER WASHER

QTY: 6

A2.



3/8-16" U-NUT

QTY: 6

B.



3/8-16 X 1" BUTTON HEAD BOLT

QTY: 2


B1.



3/8" FLAT WASHER

QTY: 4

B2.



3/8-16" NYLON LOCK NUT

QTY: 4

C.



3/8-16 X 1" CARRIAGE BOLT

QTY: 2

Reference this page throughout the install

HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 1

Located on the passenger side above the frame rail, unplug the main wiring harness shown on figure 1 by pulling the tab back shown on figure 2.



FIG. 1



FIG. 2

HONEY BADGER FRONT BUMPER


2024-UP/F-150

REMOVAL


□ STEP 2

Use a 21mm socket to remove the three bumper mounting bolts at each frame horn. (Repeat on other side) Remove OEM bumper from vehicle.

*****Recommended to have someone stabilize the bumper while removing mounting bolts to prevent the bumper from falling*****



INSIDE



OUTSIDE


HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 3

Using a (7mm socket), remove the intercooler shroud bolts located on top and bottom of the frame horns.




HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 4

Using a T20 remove the shutter motor located on the passenger side of the intercooler shroud. *****Set aside for it will be reused later in the install*****




HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

☐ STEP 5

Using a 15mm socket, remove the OEM tow hooks.



HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 6

Use your preferred cutting tool to remove the crash bars located on each side of the vehicle. ****Paint after cutting to prevent future rust****




HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 7

Remove the 6x OEM bolts holding the air dam using a (13mm socket).





HONEY BADGER FRONT BUMPER

2024-UP/F-150

REMOVAL

□ STEP 8

Next, Using a (T30) remove the fog lights.





HONEY BADGER FRONT BUMPER 2024-UP/F-150

REMOVAL

□ STEP 9

Using a (13mm socket) remove the mounting plates to expose the ACC and wire harness.




HONEY BADGER FRONT BUMPER 2024-UP/F-150


REMOVAL

□ STEP 10

Remove the parking sensors and bezels from the stock bumper, You can now remove the wire harness and set aside for install. ****Take note of the location and orientation prior to removal. This will be referenced later on in the install****



**SPREAD THESE
TWO TABS TO RELEASE
THE PARKING SENSORS
FROM THEIR MOUNTING
RINGS.**



**PRESS THESE TWO
TABS IN TO RELEASE THE
MOUNTING RINGS FROM
THE BUMPER.**


HONEY BADGER FRONT BUMPER 2024-UP/F-150

REMOVAL

☐ STEP 11

Trim the mounting tabs to accommodate for the thickness of the material on your new bumper.

BEFORE



AFTER



☐ STEP 12

If your vehicle is equipped with Adaptive Cruise Control, relocate the sensor at this time with the ADD Relocation Bracket (part# AC19005101NA - sold separately).



HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 13

Now would be a good time to install any light options with the provided light mount brackets with the provided **(B, B1, B2, C)** 3/8" hardware using a (9/16 wrench) and a (5/32 allen).





HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 14

Install the sensor bezels in the same orientation from the stock bumper. Next install the wire harness and plug the sensors into the bezels.



HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 15

If your sensor bezels do not match the sensor cutouts on the bumper trim as need using a (razor blade) as shown below.




HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 16

Install the provided (A2) 3/8" nut clips. (Repeat on other side)




HONEY BADGER FRONT BUMPER 2024-UP/F-150

INSTALL

□ STEP 17

Place the nut plate for the OEM tow hooks into the frame to be used later. You will not be able to get this in there after the bumper is set in place.



HONEY BADGER FRONT BUMPER 2024-UP/F-150

INSTALL

☐ STEP 18

Ensure to install the Shutter Motor Bracket by following the guide. <https://www.addictivedesertdesigns.com/collections/2024-ford-f-150-raptor-raptor-r-front-bumpers/products/f-150-raptor-shutter-motor-kit>

Plug the shutter motor removed from **step 4** into the original wire harness location and use zip ties to secure it to the wire harness.



HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 19

With the help from another installer, position the bumper on the truck and with the provided (A, A1) 3/8" hardware using a (9/16 socket).



HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

□ STEP 20

Install the tow hooks with the OEM hardware removed from **step 5** using a (15mm socket).




HONEY BADGER FRONT BUMPER 2024-UP/F-150

INSTALL

□ STEP 21

Plug in the wire harness. ****Ensure the clip is fully pushed down when plugged in as shown below****



HONEY BADGER FRONT BUMPER

2024-UP/F-150

INSTALL

☐ STEP 22

Trim the inner wheel well using a (razor blade/scissors) as shown below.



HONEY BADGER FRONT BUMPER 2024-UP/F-150

FINAL

☐ STEP 23

Stand back and enjoy your new ADD Honey Badger Front Bumper.

Check and re-tighten all mounting bolts after 100 miles and periodically thereafter.



THIS PRODUCT IS PROTECTED BY ONE OR MORE U.S. PATENTS
WWW.ADDICTIVEDESERTDESIGNS.COM/PATENTS

FOR ADDITIONAL SUPPORT OR TECHNICAL QUESTIONS,
PLEASE CALL 480-671-0820 OR
EMAIL INFO@ADDICTIVEDESERTDESIGNS.COM