



LED LICENSE PLATE LAMPS

(2004-2014 F150)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) License Plate Lamps

TOOLS REQUIRED

Flathead Screwdriver

SKU # T596989 / T596990

STEP 1




Using a flathead screwdriver, insert the screwdriver into the cutout in the license plate lamp housing to depress the plastic retaining tab. Once depressed, pry the light outwards.

STEP 2



Turn the light connector counter clockwise to separate the light housing from the light socket. Remove the light bulb from the light socket.

STEP 3



Plug the LED license plate lamp into the vehicle.

Note: The LED license plate lamp is polarized. If the light does not initially function, plug the LED light connector into the light socket in the opposite direction.

STEP 4



Carefully tuck the LED light wires into the light housing, then secure the vehicle light socket into the LED light housing by turning the socket clockwise.



STEP 5

Press the LED license plate lamp into the bumper. Repeat steps 1-4 to the opposite side.

Installation is now complete.