

LED LICENSE PLATE LAMPS

(2004-2014 F150)

ΙΝΙΣΤΔΙ	LATION	INSTRUCTIONS	
		114.31 (24.1.114.114.3	

CONTENTS TOOLS REQUIRED

(2) License Plate Lamps Flathead Screwdriver





STEP 1

Using a flathead screwdriver, insert the screwdriver into the cutout in the license plate lamp housing to depress the plastic retaining tab. Once depressed, pry the light outwards.



STEP 2

Turn the light connector counter clockwise to separate the light housing from the light socket. Remove the light bulb from the light socket.





Plug the LED license plate lamp into the vehicle.

Note: The LED license plate lamp is polarized. If the light does not initially function, plug the LED light connector into the light socket in the opposite direction.



STEP 4

STEP 3

Carefully tuck the LED light wires into the light housing, then secure the vehicle light socket into the LED light housing by turning the socket clockwise.





STEP 5

Press the LED license plate lamp into the bumper. Repeat steps 1-4 to the opposite side.

Installation is now complete.