Axil SUSPENSION PARTS

HD CENTER LINK

(2011-2024 SI LVERADO 2500 / 3500)

INSTALLATION INSTRUCTIONS

CONTENTS TOOLS REQUIRED

(1) Center Link 21mm, 22mm Sockets Ratchet
Breaker Bar
Joint Removal Tool
Grease Gun

SKU # HS58057

dilli9MMOTH

STEP 1

Lift and support the front of the vehicle using a floor jack and jack stands. Remove the front wheels.

Locate and loosen the front tie rod end from the steering knuckle using a 21mm socket. Once the nut is loose, use a joint removal tool to disconnect the joint from the knuckle.

Repeat this step for the opposite side of the vehicle

STEP 2

Locate the center link to pitman/idler arm mounting points. Loosen the (2) 22mm nuts on each arm. Then, use a joint removal tool to separate the center link from the pitman/idler arms.

dpiiiminoTH

With assistance, remove the center link and tie rod ends from the vehicle as an assembly. Transfer the OEM tie rod ends to the new center link, and re-install the steering assembly.

-Tighten the center link into place using the original pitman/idler joint hardware to 92 ft. lbs. -Tighten LI le de rod-eTid links to the-knuckles using the original hardware to 26 ft.1bs.4 85'1100—.-

Installation is now complete.