

advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

<https://afepower.com/contact>



MAGNUM FORCE

advanced FLOW engineering

Dynamic Air Scoop D.A.S.

Instruction Manual P/N: 54-13056S / 54-13056SL / 54-13056SR

Make: Ford

Model: Ranger

Year: 2019-2023

Engine: I4-2.3L (t)

Make: Ford

Model: Ranger

Year: 2019-2023

Engine: I4-2.0L(td) Bi-Turbo



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Scoop (Black)	05-5413056B3
A2	1	Scoop (Blue)	05-5413056L3
A3	1	Scoop (Red)	05-5413056R3

Installation will require the following tools:

T-30 Torx drive


Warranty Information available at: <https://afepower.com/contact#warranty>

Emissions Disclaimer: This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles.




Page left blank intentionally


Page left blank intentionally



A1



A2



A3




Figure A

Refer to Figure A for Step 1

Step 1: Using a T30 Torx drive, remove the two screws ① holding down the air scoop ②. Remove the scoop and set aside.



Figure B

Refer to Figure B for Steps 2

Step 2: Install the aFe Dynamic Air Scoop using the two screws ③ removed in step 1. Tighten the screws.

NOTE: Check all screws are secure after 100-200 miles.