


**LD2 FRONT BUMPER SKID PLATE
2019 FORD RANGER**

PARTS LIST:

1	LD2 Front Skid Plate
2	10mm x 35mm Hex Bolts
2	10mm x 30mm x 2.5mm Flat Washers
2	10mm Lock Washers
4	8mm x 25mm Button Head Bolts
4	8mm x 24mm x 2mm Flat Washers
4	8mm Lock Washer
1	5mm Wrench




PROCEDURE:


REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED. CUTTING MAY BE REQUIRED.

1. Carefully unwrap the Skid Plate. Place the front of the LD-2 Skid Plate on the back of the Bumper. Attach the Skid Plate to the Bumper with the included (4) 8mm x 25mm Button Head Bolts, (4) 8mm Lock Washers and (4) 8mm Flat Washers, **(Figure 1)**. Leave hardware loose.
2. Attach the Skid Plate to the threaded holes in the bottom of the frame crossmember with the included (2) 10mm x 35mm Hex Bolts, (2) 10mm Lock Washers and (2) 10mm Flat Washers, **(Figures 2—4)**.
3. Level and adjust the Skid Plate and fully tighten all hardware, **(Figure 5)**.
4. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, Do not use any type of polish or wax that may contain abrasives that could damage the finish. Mild soap may be used to clean the Skid Plate.




**LD2 FRONT BUMPER SKID PLATE
2019 FORD RANGER**




(Fig 2) Rear mounting location (arrows)


- (2) 10mm x 35mm Hex Bolts**
- (2) 10mm Lock Washers**
- (2) 10mm Flat Washers**



(Fig 3) Attach Skid Plate to bottom of crossmember



(Fig 4) Attach Skid Plate to bottom of crossmember



(Fig 5) Skid Plate installed