


**PARTS LIST: S112499**

2	Rattler Running Boards (78in)	6	8mm x 30mm Double Bolt Plates
6	Mounting Brackets	12	8mm Hex Nuts
12	8-1.25mm x 30mm Hex Bolts		
24	8mm Lock Washers		
24	8mm x 24mm x 2mm Flat Washers		

**PROCEDURE:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. ASSISTANCE IS RECOMMENDED.**

1. Start the installation under the passenger side of the vehicle. Locate the 4 plugs along the bottom edge of the body. Mounting Brackets will bolt to the 1st, 2nd and 4th threaded mounting holes, **(Figures 1—4)**. Remove the plastic plugs from each mounting location. Directly above each threaded insert is a top mounting location on the side of the body panel. Hold a Bracket up in place to help determine the mounting holes to use along the body. **NOTE:** Thread an 8mm Hex Bolt into the threaded inserts to clear paint as required.
2. Select (1) Mounting Bracket. Starting at the front of the passenger/right side, bolt the Mounting Bracket to the factory threaded holes with (2) 8mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, **(Figures 5 & 6)**. Do not tighten hardware at this time.
3. Repeat **Steps 1 & 2** to install (2) Mounting Brackets on the remaining passenger/right side mounting locations along the body panel.





RATTLER RUNNING BOARD

2019-26 1500 CHEVY SILVERADO/GMC SIERRA DOUBLE CAB  
 INCLUDES DIESEL MODELS W/DEF, 2022 SILVERADO 1500 LTD AND 2022 SIERRA 1500 LIMITED  
 EXCLUDES 2019 SILVERADO 1500 LD AND 2019 SIERRA 1500 LIMITED  
 2020-26 SILVERADO/SIERRA 2500/3500 DOUBLE CAB (INCLUDES DIESEL W/DEF)


4. Select (1) Running Board. Place the Running Board on top of the Brackets. **IMPORTANT:** Do not slide, (front to back or rotate), the Running Board on the Brackets or damage to the finish may result. Locate the channel opening in the bottom of the Running Board. Select (3) 8mm Double Bolt Plates. Insert the Bolt Plates into the channel in the bottom of the Running Board closest to the Brackets, (**Figure 7**). Lift the Running Board up and guide the studs through the Brackets.
5. Attach the Running Board to the Brackets with (6) 8mm Flat Washers, (6) 8mm Lock Washers and (6) 8mm Hex Nuts, (**Figures 8 & 9**).
6. Level and adjust the Running Board and fully tighten all hardware. **WARNING: DO NOT USE ELECTRIC TOOLS OR OVERTIGHTEN THE 6mm HARDWARE. EXCESSIVE TIGHTENING OF 8mm HARDWARE WILL RESULT IN THE BOLT PLATE BREAKING.**
7. Repeat **Steps 1—6** to install the Running Board on the driver/left side.
8. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish. Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.


**Passenger/right side Installation Pictured**




**Passenger/right side Installation Pictured**




(Fig 5) Mounting Bracket illustration




(Fig 6) Passenger front Bracket installed



(Fig 7) Insert Bolt Plate in the bottom of the channel on the Running Board



(Fig 9) Passenger Running Board attached to Bracket



(Fig 8) Passenger front complete install

**NOTE: DO NOT OVER TIGHTEN HARDWARE ON BOLT PLATE.**  
**WARNING: OVER TIGHTENING HARDWARE MAY RESULT IN DAMAGING BOLT PLATE.**

**Torque Value: 14-16N.m (10-12ft-lbs)**