

## advanced FLOW engineering

## Instruction Manual P/N: 46-39109

## 87mm Throttle Body for GM Trucks V8-5.3L

Silverado 1500	2014-2023	Sierra 1500	2014-2023
Silverado 1500 LD	2019-2019	Sierra 1500 Limited	2019-2019
Silverado 1500 LTD	2022-2022	Sierra 1500 Limited	2022-2022
Suburban	2015-2023	Yukon	2015-2023
Tahoe	2015-2023	Yukon XL	2015-2023



Qt	ty.	Part Description	
	1	87mm Throttle Body	
1	1	Throttle Body Adaptor, 80mm to 87mm	
	1	Throttle Body Gasket	
4	4	M6 x 1.0mm x 40mm Screw, Hex Hd Flanged	
4	4	M6 x 1.0mm x 16mm Screw, Socket Hd Cap	

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- · Retain factory parts for future use.

- 1. Disconnect the battery.
- 2. Remove the air intake tube from the vehicle.
- 3. Disconnect the electrical connector from the factory throttle body.
- 4. Remove the four (4) screws retaining the factory throttle body.
- 5. Remove the factory throttle body.
- 6. Clean the gasket surface at the intake manifold and replace the gasket if necessary (not supplied).
- 7. Install the supplied aFe Throttle Body Adaptor onto the intake manifold using the four (4) supplied M6 x 1.0mm x 16mm screws. Tighten to factory specifications (10nm or 89 in. lbs.).
- 8. Install the supplied aFe 87 mm Throttle Body and the supplied gasket onto the aFe Throttle Body Adaptor using the four (4) supplied M6 x 1.0mm x 40mm flange head screws. Tighten to factory specifications (10nm or 89 in. lbs.).
- 9. Connect the electrical connector to the aFe 87mm Throttle Body.
- 10. Install the air intake tube back into the vehicle.
- 11. Reconnect the battery.
- 12. Installation is now complete.

NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles