




ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS



PROFESSIONAL INSTALL RECOMMENDED

2015 FORD F-150

PART#: Z335731 / Z335731-KIT-C

FRONT ROOF LED LIGHT MOUNTS

PARTS ARE PRELIMINARY. ALL RIGHTS RESERVED - COPYRIGHT ©2015 - ZROADZ LED, INC.

PARTS INCLUDED

- (1) - Driver Side Roof Mount Upright
- (1) - Passenger Side Roof Mount Upright
- (1) - Driver Side Curved Coupler
- (1) - Passenger Side Curved Coupler
- (1) - Driver Side Straight Coupler
- (1) - Passenger Side Straight Coupler
- (1) - Hardware Pack



* Simulated Rendering. Not actual parts.

LED LIGHTS INCLUDED

- Z335731 - No LED Lights Included
- Z335731-KIT-C - (1) ZROADZ 52" Curved LED Light Bar

HARDWARE INCLUDED

- | | |
|---|--|
| Z335731
<ul style="list-style-type: none"> (1) - Weather Proof Rubber Grom (1) - 3/16" Dia. Vee Clip Mount (2) - 1/2" x 20" Hex Nut (2) - 1/2" Split Lock Washer (8) - 10-32 x 3/32" Self-Drilling Head-Air Cap Stainless Steel Screws (8) - 1000" Nylon Torx Hex Screws (1) - Driver Side Bottom Floor Gasket (1) - Passenger Side Bottom Floor Gasket | Z335731-KIT-C
<ul style="list-style-type: none"> (1) - Weather Proof Rubber Grom (1) - 3/16" Dia. Vee Clip Mount (2) - 1/2" x 20" Hex Nut (2) - 1/2" Split Lock Washer (8) - 10-32 x 3/32" Self-Drilling Head-Air Cap Stainless Steel Screws (8) - 1000" Nylon Torx Hex Screws (1) - Driver Side Bottom Floor Gasket (1) - Passenger Side Bottom Floor Gasket (1) - 1/4" x 1/8" Bit (2) - M8 Torque Proof Bolt (2) - M8 Split Lock Washer |
|---|--|

TOOLS REQUIRED

- Tapered 1/2" Drill bit or car reamer
- Drill
- Air Hose & Nozzle
- Alcohol Cleaning Solution
- Cleaning Rag
- Socket Set & Ratchet Tool
- Ratchet Extensions
- Various Wrenches
- Drives or Straps
- Torq Bit Set
- Heat Gun

MATERIALS NEEDED: Clear RTV Silicone 1/2" x 1/4" (2) 3/4" Dia. Shrink Tube

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct, our tech department can be contacted at orders@zroadz.com to verify fitment and assist with technical questions. All other inquiries can be directed to orders@zroadz.com. In the event you do not have internet access please call 844-893-8040.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS. * IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.

LED LIGHT BRACKET INSTALLATION

- STEP 1:** 1) Drop OEM headliner down to allow access to the inside of vehicle roof mounting per industry "R&R" method.



STEP 2

2) From above, if your vehicle has this feature, remove or push to the side roof seam moulding. (The Black Rubber Strip near both top edges of vehicle cab.)





ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ, INC.



FIG 3



FIG 4

STEP 3

3) Ford F-150 model vehicles feature an interior cab structure that will require meticulous fabrication to remove material and enable access to the through bolt after the cab hole has been drilled.

In Step #5 you will drill your hole, after this is completed, continue to carve out access inside the skeletal cavern.

STEP 4

SEE FIGURE 4

4) Obtain the supplied roof mount base gaskets to use as a template to locate the drill hole location. Lay the gasket in the roof channel.

DO NOT REMOVE THE GASKETS/ADHESIVE LINER.



FIG 5

SEE FIGURE 5

Make sure the gasket is centered transversely (from right to left) in the channel. The front to back location of the gasket should be 1.4" from the top edge of the windshield glass to the end of the front of the gasket.

DRILLING VEHICLE ROOF



FIG 6

PRO TIP

DO NOT ATTEMPT INSTALL UNLESS YOU HAVE A CAR REAMER OR TAPERED 1/2" METAL DRILL BIT!

STEP 5

SEE FIGURES 6-7-8-9

5) Using the gasket hole as a locator, center punch the pilot hole location.

With the interior roof free and clear, drill a 1.4" hole in the roof gutter to pilot the mounting hole. Use a car reamer (as seen in Figure #7) or tapered 1/2" metal drill bit to open the hole to a final diameter of 1.2".

With the holes drilled through, clean off all drilling debris and flash **INSIDE AND OUTSIDE OF THE DRILL HOLE LOCATIONS**. This is a very important to create a flush sealing surface and you do not want to leave any chance of rust occurring.

Perform this step for both sides of the roof.



FIG 7




FIG 8

FIG 9

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



ZROADZ
DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT © 2016 - ZROADZ, INC.



FIG 10



FIG 11

STEP 6

SEE FIGURES 9 - 12

6) Clean the base of the supplied roof brackets with alcohol. Once dry remove the liner of the base gaskets from step #4 and apply the gasket to the base of each bracket.

STEP 7

SEE FIGURE 11

7) Before you install the bracket to the roof, check that the threads on the post after coming through the roof are clean.



FIG 12

INSTALL ROOF MOUNT TO ROOF



FIG 13

STEP 8

SEE FIGURE 14

8) Use a thin layer of clear RTV Silicone around outside of each drilled hole to help with weather proofing and sealing.



FIG 14

STEP 9

SEE FIGURE 15

9) With the roof and channel area debris free and wiped down clean with alcohol cleaning solution, align the ZROADZ LED Mounting bracket to the roof and insert the through bolt threads down into the drilled hole.

Make sure the outside of the upright is coated black and says ZROADZ while the inside of upright presents the aluminum skin. Inspect your work to make sure you are happy with the position and then repeat for other side.



FIG 15

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



ZROADZ
DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

FIGURES ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2018 - ZROADZ LED, INC.



FIG 16



FIG 17



FIG 18

STEP 10

SEE FIGURES 16 - 18

10) With the two brackets installed, check that the threads on the post after coming through the roof are clean. Install the split lock washer and the hex nut and tighten securely.

STEP 11

11) Check to make sure the upright is secured and firmly attached to top side of roof.



FIG 19

STEP 12

SEE FIGURE 19 - 21

12) Obtain the supplied security lock washer and tool bit from the hardware pack. With a friend's help, install the 52" light to the brackets with the wire on the drivers side. Tighten hardware by giving the tool bit some extra leverage.

STEP 13

SEE FIGURE 22

13) Secure the wire to the driver bracket with supplied wire clip and nut. Leave slack in the wire from LED to the wire clip for some movement & available adjustment.

LED LIGHT INSTALL



FIG 20



FIG 21



FIG 22

LED LIGHT ROOF MOUNT INSTALLATION - CONTINUED



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT © 2016 - ZROADZ LLC, INC.



FIG 23



FIG 24

STEP 14

SEE FIGURE 23

14) Cut the LED light wires. Leave enough room for the insulation to be removed and the red and black wires to pass through the roof via the "Through Bolt Down Tube".

STEP 23

SEE FIGURE 24

15) Trim back a large amount of the insulation sheath of the LED Wires so that you can slip them through the rubber weather proofing boot.

To expose the wires, a sharp razor could easily split open the insulation sheath.



FIG 25



FIG 26

STEP 16

SEE FIGURES 25 & 26

16) Install 1/4" heat shrink insulation over wires as shown in Figure #25. Shrink insulation with heat gun or similar.

WIRING PLUMBING



FIG 27

STEP 17

SEE FIGURES 27

17) Use a 50/50 mix of dish soap and water solution to install supplied boot over wire as shown on page #2 Fig. 5.

Pass the wire through the tube. Use a liberal amount of solution on the bracket around the area where the boot installs to aid in slipping the boot over the post.



FIG 28

FIG 29



FIG 30

LED LIGHT BRACKET INSTALLATION - CONTINUED



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 31



FIG 32

STEP 18

SEE FIGURE 31

18) Stuff the boot into the bracket opening and over the down tube upright.

STEP 19

SEE FIGURE 33 - 34

19) With the rubber boot fully sealed (as seen in Figures #33 & 34) you are now ready to finish wiring up the LED Light bar to a wiring harness.

After wiring is complete, re-install vehicle's interior in the reverse order it was removed according to industry "R&R" method.



FIG 33



FIG 34

STEP 20

20) Wire LED Light with a ZROADZ optional wiring harness kit (part # Z3000205-A) or by utilizing a compatible custom wiring harness. ZROADZ recommends LED Lights be wired with ZROADZ harness kit (part # Z3000205-A).

STEP 21

ADJUSTMENT TIPS

21) To adjust the angle of your Light Bar, rotate the LED(s) to adjust the angles till your desired light pattern is reached. There will be minimal adjustment due to curved light bar orientation. You may then tighten the hardware and secure everything into place. Be careful not to over tighten the mounting hardware.

It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed.

FINAL INSTALLATION



FIG 35



FIG 36

FIG 37



FIG 38

LED LIGHT ROOF MOUNT INSTALLATION - COMPLETE



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

ZROADZ PRODUCT WARRANTY

ZROADZ PRODUCT WARRANTY

ZROADZ warrants its grille products to be free from defects in material and workmanship for the lifetime of the grille. ZROADZ warrants the finish of its grille products for a 3 year period beginning at the time of sale to the end user. These warranties are limited warranties and do not cover abuse, modification or improper installation nor do they cover finish failure caused by caustic cleaning agents, road salts or other chemicals. ZROADZ reserves the right to repair or replace a defective product at its sole discretion. Any ZROADZ product must be returned to ZROADZ for warranty consideration and must be returned at the customer's expense. In the event that the product is deemed to be defective, the repaired or replaced item will be returned via a surface shipping method to the customer at ZROADZ expense. No provision is made for any labor, rental car or other costs incurred by the failure of its products.

LED LIGHTING EQUIPMENT INSTALLATION / DISCLAIMER

WARNING

PLEASE CONSULT YOUR LOCAL AUTOMOTIVE ELECTRICAL PROFESSIONAL FOR INSTALLATION SERVICES AND ADVICE. ZROADZ IS ONLY EQUIPPED TO PROVIDE BASIC TECHNICAL ASSISTANCE DUE TO THE DIVERSITY OF VEHICLES, VEHICLE OPTIONS & MODIFICATIONS AND LIGHTING CONFIGURATION OPTIONS AVAILABLE. ZROADZ cannot be held liable due to improper component installation and / or faulty wiring.

GENERAL CAUTIONS

LED Lights & LED Light Bars operate at relatively high currents and should only be installed by qualified personnel with experience in switched / relayed high draw DC Circuits.

- Light Bars are designed for use only with standard 12v DC power systems
- Light Bars are for OFF-ROAD USE ONLY. Check your local laws & regulations regarding vehicle mounted lights.
- Some Light Bars are equipped with waterproof connectors while others are simply pig-tailed
- Red Wires = POSITIVE | Black Wires = NEGATIVE
- ALWAYS install your lights on a fused circuit. Basic fusing guidelines: maximum 5A for every 10' of LED Light Bar.

GENERAL USE, INSTALL AND ADJUSTMENT TIPS

NOTE 1: ZROADZ LED Light Bars themselves are for OFF-ROAD USE ONLY.

NOTE 2: Light Bars depending on the configuration of your vehicle and its options and/or modifications may need to be adjusted for appropriate beam projection. To adjust the angle of your light bars simply loosen the mounting hardware on either side of each light bar, rotate the light bar to adjust the angle, then tighten the hardware once the desired angle is achieved (please be careful not to over-tighten the mounting hardware or scratch the protective powder-coat finish). It is best to adjust the angle with the vehicle on level ground with the lights facing a wall, garage door or other solid barrier at a distance of approximately 25-30 feet.

NOTE 3: Please consult a qualified automotive electrical professional for light bar wiring installation.

NOTE 4: An optional universal wiring harness (part Z9900295-A) is also available that includes high-heat & oil/fuel resistant wires, waterproof connector, 12v relay, 12v rocker switch, inline fuse holder. Our universal wiring harness significantly expedites the installation process but is not a vehicle specific "Plug & Play" product and does not eliminate the need for a professional installation.

Please contact your local ZROADZ dealer for more information or visit www.zroadz.com.

PRODUCT CARE INFORMATION

PRODUCT CARE INFORMATION

Wash regularly as you would when caring for your vehicles. Never use dish soap. Never leave wet water spots as that may leave a blemish.

MATTE BLACK FINISH

Paint warranty applies to defects in material and / or workmanship. It does not cover the matte finish surface appearance.

To enjoy the matte appearance for many years to come, please follow these owner care and maintenance tips. Get a no-shine matte car wash soap that uses no fillers, no silicones, and won't strip your matte paint of its layer of protection.

Do not use wax, detail spray, armorallik, or any products made for normal paint. Use only products specifically developed for matte finish paint. Do not use products that are even mildly abrasive, such as polishes, glazes, or rubbing compounds. Do not use mechanical cleaners or polishers. Do not use terrycloth, cloth, or paper towels. Do not rub the finish vigorously, this will burnish the paint finish, causing a permanent shiny spot. Shiny spots cannot be removed.

Do not use commercial car wash facilities or their shine enhancement products. Most car wash brushes, large mechanized "towers," and shine enhancement products can damage matte paint.

Remove foreign substances such as insect remains, tar, and road debris using a soft applicator and a mild solvent, acetone and soak area before cleaning—rub lightly.

Hand-wash with a soft wash mitt and mild cleaning product safe for matte paint. Use microfiber cleaning cloths with alcohol-based window cleaner for basic surface clean-up.

GLOSS BLACK FINISH

ZROADZ with Gloss Black Powder Coated Finish may be washed regularly as you would when caring for your vehicles finish using soap and water. ZROADZ should be washed at the same time that you wash the vehicle. As a general rule, anything you use to clean your vehicles painted surfaces can be used to clean and maintain your ZROADZ grille. A Gloss powder Coated Finish can be cared for in the same fashion that you would care for your vehicles factory paint job. Never leave wet water spots as that may leave a blemish.

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.