



MUD GUARDS

(2015-2020 F-150 WITH OEM FENDER FLARES)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) Front Mud Guards
(2) Rear Mud Guards
(8) Phillips Screws
(2) U-Clips
(2) Push Clips
(2) 5mm Allen Bolts
(8) Flat Washers
(10) Spring Clips

TOOLS REQUIRED

Panel Removal Tool
Phillips Screwdrivers
5mm Allen Key/Socket
5.5mm Socket
10mm Socket
Socket Wrench
Drill
1/8" Drill Bit
Exterior Detailer/Isopropyl
Alcohol

SKU # T546991

**STEP 1
(FRONT)**

Remove the (1) push clip at the bottom of the fender flare, pull it away enough to remove the (1) Phillips screw in the fender liner.

STEP 2

Using the mud guard as a template, align the notch in the mud guard to the original screw-hole in the vehicle. Once aligned, drill a 1/8" hole through the mud guard and the fender flare.


STEP 3

Clean the surface of the fender flare using exterior detailer/isopropyl alcohol. Peel back the film on the double sided tape, and align the mud guard onto the vehicle. In the drilled hole, reinstall the original 5.5mm bolt into the fender liner. Install (1) plastic push clip into the bottom of the fender flare.

STEP 4

Using equal pressure, stick the double sided tape to the fender flare. Install (2) spring clips onto the mud guard and the fender flare at the indicated areas on the mud guard. Once the spring clips are installed, installation is complete.

STEP 5 (REAR)




Remove the (1) 10mm bolt and (1) push clip from the rear fender.

STEP 6



Clean the fender flare surface using exterior detailer/isopropyl alcohol. Insert (1) U-Clip into the top of the fender flare where the previous push clip was installed.

STEP 7

Peel back the double sided tape, and align the mud guard to the fender. Install (1) Phillips screw into the U-Clip located at the upper part of the flare. Firmly press down the mud guard adhering the double sided tape to the flare. Install (2) spring clips onto the mud guard and the fender flare.

STEP 8

Install (1) M6 Allen Bolt into the bottom of the fender flare. Installation is now complete.